FLOTELO

Installation brief

SYNTHETIC SAMPLE · NOT A CUSTOMER DOCUMENT

Job: Utility installation · Brno warehouse

Dates: 19–21 October 2026

Crew: Petr Novák, Lukáš Dvořák

Vehicles: MAN TGM 15.250, Ford Transit Custom

Machine: JCB 3CX · STR 03

Work instructions

1. Check utility markings and secure the work area.
2. Prepare the trench and install the connection.
3. Inspect, backfill and hand over to the customer.

Access: west gate. Confirm access with Martin Svoboda.